



rabalux®

74234
74235
74236
74237

Touch switch button
1st time touch: low brightness
2nd time touch: middle brightness
3th time touch: high brightness
4th time touch: turn off the lamp



USB power cable included
Input: DC5V 0.5A